



## NATURHAUS Furniture Polish

**Product information:** NATURHAUS *Furniture Polish* is a specially formulated waterborne maintenance product with natural waxes and shellac used to clean, protect, and build sheen on wooden furniture bringing out its natural beauty. It helps loosen and gently remove fingerprints, smudges and dirt. Its regular use as part of a protective maintenance program will help build a dirt-resistant, anti-static, breathable, water-resistant coating of natural wax and shellac.

*Note:* If finish is unknown, first try on an unnoticeable area to check results.

**Ingredients:** Unbleached beeswax, carnauba wax, shellac, cosmetic emulsifier and purified water.

**Application:** NATURHAUS *Furniture Polish* should be applied directly to the furniture surface, allowed to dry for 15 to 30 minutes, then buffed lightly with a dry lint-free cloth. If desired, the product can also be added to warm water and used to clean furniture with a soft clean cloth moistened in the solution.

**Physical properties:** Density: approx. 1.00 g/ml; viscosity approx. 14 seconds (ISO 2431, 4 mm).

**Test specifications:** DIN EN 71-3 (security requirements for toys intended for children).

**Hazard classification:** The product does not require labelling according to *Council Directive 1999/45/EEC*.

**Storing conditions:** Keep the original container tightly closed and store in a dry, frost-free area. The product can be stored for up to 2 years.

**Security and disposal information:** Keep product away from children. Empty containers completely and send to a licensed recycler. Dispose of used or contaminated product in accordance with local authority requirements. For further information, please ask for our EC material safety data sheet.

**Product No:** 02600

<b>Pack size,</b>	250 ml	1 l	3 l	10 l
<b>Container material:</b>	PE/PP	PE/PP	PE/PP	PE/PP