



NATURHAUS Oil & Wax Remover

Product information: NATURHAUS *Oil & Wax Remover* is a highly efficient alkaline cleaner specifically formulated to remove oil, grease, tar, gums, waxes and resins.

Ingredients: Anionic and non-ionic cleaning agents, alkali hydroxide, phosphates, complexing agent, glycol ether, purified water.

Application Range:

- ① Cleaning of spray guns used for aqueous coating products, e.g. NATURHAUS *Shellac Primer*
- ② Removing of oil & wax residues from brushes
- ③ Removing of oil & wax residues from rolling machines
- ④ Cleaning of hot wax spray guns, e.g. mk "Duoline"
- ⑤ Removing of oil & wax surfaces from e.g. floorings

Mixing ratios:

Type of application:	①	②	③	④	⑤
NATURHAUS <i>Oil & Wax Remover</i> :	1 part	2 parts	1 part	1 part	1 part
Water:	5 parts	3 part	1 part	-	1 part
NATURHAUS <i>Alcohol Thinner (Prod No. 92801)</i> :	5 parts	1 part	-	-	-

Application: ① **Cleaning of spray guns used for aqueous coating products:**
Circulate cleaning solution for 5 minutes in the spray gun and rinse thoroughly with tap water.

② **Removing of oil & wax residues from brushes:**
Soak brushes for approximately 2 to 3 hours in the cleaning solution. Then remove and and rinse thoroughly with tap water. Persistent residues can be removed using compressed air or respectively a rough pad or a rough wooden surface.

③ **Removing of oil & wax residues from rolling machines:**
Circulate cleaning solution for 5 to 10 minutes on the rolls, remove residues with a lint-free cloth and rinse thoroughly with tap water.

④ **Cleaning of hot wax spray guns:**
Empty spray gun, allow to cool and fill the beaker with the cleaning solution. Close the cover and allow to act for 30 to 60 minutes. Remove cleaning solution and rinse sytem thoroughly with tap water. Do not leave cleaning solution for more than 1 hour in the spray gun to avoid corrosion of aluminium parts. In case of persistent contamination repeat cleaning procedure.

⑤ **Removing of oil & wax surfaces:**
Tape thoroughly glass, stone tiles and metallic parts. Apply enough cleaning solution to saturate the surface and machine grind using a green pad (abrasive texture). Remove residues after 2 to 3 minutes with a suitable wet cleaner and repeat cleaning with tap water. If necessary, repeat the procedure. All wooden surfaces must finally be neutralised with a solution consisting of 1 part of NATURHAUS *Wood Restorer (Prod. No. 09200)* and 3 parts of water. Darkening reactions of woods rich in tanning agents are thereby reversed. Allow to dry completely and build up a new surface using our oil and wax products.

Physical properties: Density: approx. 1.1 g/ml

Hazard classification: Xi (irritant) according to *Council Directive 1999/45/EEC*.

Storing conditions: Keep the original container tightly closed and store in a dry, frost-free area. The product can be stored for up to 2 years.

Security and disposal information: Keep product away from children. Wear suitable gloves and eye protection. Empty containers completely and send to a licensed recycler. Dispose of used or contaminated product in accordance with local authority requirements. For further information, please ask for our EC material safety data sheet.

Product No: 09100

Pack size,	1 l	3 l	10 l	25 l
Container material:	PE/PP	PE/PP	PE/PP	PE/PP



The information herein is given in good faith. The attention of the user is drawn to the possible risks incurred by using the product for any other purpose other than that for which it is intended. No warranty, express or implied, is made. In case of ambiguities between the German and the English version, the actual German version will be valid. (Version 004 / January 2005)